




Horn drückknopf schaltet Plus(+)
 Horn push positively connected(+)
 Bouton avertisseur connecté positivement(+)
 Signalhornknappen kopplar plus(+)
 Horn drückknopf schaltet die(+)
 El pulsador de bocina conecta positivamente(+)
 Comando avvisatore di serie connesso sul positivo(+)



*in Deutschland nicht zugelassen



Horn drückknopf schaltet Minus(-)
 Horn push negatively connected(-)
 Bouton avertisseur connecté négativement(-)
 Signalhornknappen kopplar minus(-)
 Horn drückknopf schaltet die(-)
 El pulsador de bocina conecta negativamente(-)
 Comando avvisatore di serie connesso sul negativo(-)



*in Deutschland nicht zugelassen

