

Telephone:
Fax:
VAT Registration No.:

INSP - Inspection service

Press and hold button [A] **84764**.

Switch ignition ON.

The letters "OIL" will appear in the trip recorder display.

Release button [A].

Press and release button [A].

The letters "INSP" will appear in the trip recorder display.

Pull out button [B] for approximately 2 seconds to reset the display.

